

Wire Guide Outdoor Screens

User Guidelines and Care Instructions – Clear PVC or Mesh PE/PVC

Congratulations on your acquisition of New Zealand's premium outdoor wire guided screen system. We trust this will bring you plenty of protected outdoor enjoyment.

To ensure you get a long and hassle-free life out of your wire guide screens, below are simple care and maintenance recommendations.

1. Screens made from Clear PVC will expand or shrink depending on ambient temperatures. When warm, the Clear PVC will be soft and pliable; when cold, the blind will tighten up and the Clear PVC becomes less pliable. This may affect the ease of movement of the screen on and off the roller.
2. Always guide your screen up or down by using the removable crank handle properly inserted into the gearbox spindle eye. Remove the handle from the gearbox when not in use as damage may occur if the unrestrained handle is left hanging from the spindle eye.
3. If your screen is rolled up when wet this may result in a milky opaqueness of the Clear PVC. This cloudiness should dissipate naturally when the screen is rolled down in warmer conditions.
4. We recommend you keep your screen rolled up when not required; this reduces the risk of damage to the wire guide system, particularly during adverse weather, and extends the life of the screen.
5. Even though your wire guide screen is designed to withstand moderate wind we recommend that, if strong winds (>40km/h) are predicted, you secure your screen in the up position.
6. All screens require regular cleaning; this enhances the aesthetics of your screen, prevents scratching of Clear PVC and should prevent the formation of mould. While a regular hose-down with clean water removes a lot of the collected dust, we do recommend a wash with warm water and a little dishwashing liquid using a soft sponge or chamois. Allow to dry naturally or use the chamois to wipe away excess water.

Never use a hard scratchy cloth or brush, abrasive cleaning agents or solvent-based products such as acetone or petrol to clean your screen even if the cleaning agent packaging states it is safe to use on PVC products. Note that intense rubbing may leave scuff marks and scratches.

VuPlex or Plexus Sprays can be used to rejuvenate your Clear PVC screen and reduce the accumulation of dust and other dirt. This can be obtained from our Showroom at **413 Queen Street West, Hastings**.

7. Avoid direct and intense heat – keep any intense heat source such as patio heaters and BBQ's well away from your screen. Note that sparks eg from a fire-place or fireworks may leave burn marks on the screen.
8. We also suggest you add your new screens to your household insurance – that way you are covered in the unlikely event of them being damaged.

And if you are in any doubt about the operation or maintenance of your wire guide screens just call us on

06 878 6300

Now sit back, relax and enjoy your Wire Guide Screen!